Part of the AlphaSAFE Antimicrobial Line

APPLICATION INSTRUCTIONS

#### 1. PRODUCT DESCRIPTION

AM Textile is a VOC-exempt, environmentally friendly solvent-based coating that creates an extremely water repellent hydrophobic surface. Treated fabrics will shed water quickly while remaining breathable. AM Textile is UV resistant and has no residual odor. Treated fabrics remain soft and flexible. AM Textile bonds with fibers to create long-term durable performance and enhanced tensile strength. Treated fibers are covered in a self-lubricating dry film that reduces friction to improve performance and reduce wear. AM Textile is non-flammable and will decrease flame spread in treated fabrics.

## 2. SURFACE PREPARATION

Be sure that the substrate material is clean and free of debris, oils or other contaminants that may prevent the
product from saturating into the fabric.

### 3. APPLICATION

NOTE: As with any new material, always test application and finished properties on a low value test article or panel before working on valuable surfaces.

- Mix or shake the container to ensure product is mixed thoroughly.
- Ambient temperature should be above 60°F (15°C) during application.
- Application may be done with spray, dip, brush, or wipe. Select the method that best fits the size, shape and
  composition of the material that is being coated. Ensure the substrate is well wetted/saturated with the coating
  regardless of application method.
- Place coated fabric in an open environment and allowed to dry.
- Once cured, a second coat may be added if added protection is desired.

Part of the AlphaSAFE Antimicrobial Line

APPLICATION INSTRUCTIONS

#### 4. DRYING & CURING TIMES

Solids	14%
Drying Time	Approximately 20 minutes at ambient temperatures. Drying time is dependent on the weight, tightness of weave, fabric type and air temperature. arefully check the coated fabric to ensure that it is dry to the touch prior to handling.
Drying Time (Accelerated)	Pass through an oven with free-flowing air (convection type) at a maximum temperature of 110°F (43°C). Ensure that the fabric can withstand the accelerated temperatures prior to putting it into the oven.
Curing Time	Approximately 12 hours at ambient temperatures.

# 5. COVERAGE RATE

- Non-absorbent Plastics: Approximately 2,850 square feet per gallon (47 square meters per liter) at dry film thickness of 3 microns.
- Thin Fabrics: Approximately 1,900 square feet per gallon (47 square meters per liter)
- Thick Fabrics: Approximately 1,000 square feet per gallon (47 square meters per liter)
- Coverage rate will vary significantly depending on the absorbency of the substrate material. Contact your ALPHATEK representative to discuss potential coverage for the planned substrate material.

### 6. STORAGE STABILITY & SHELF LIFE

The shelf life is one year when stored in the original, unopened container. Store containers in a well-ventilated and covered area away from extreme heat and moisture. Contact your ALPHATEK representative if you have any questions about the products or its uses.

#### 7. SAFETY

Refer to the Safety Data Sheet for this product prior to use.